
Summary: ARP Functionality

Test designed by Rustamov Arsen from IB-93 on 01.10.2022

Description: Verify that **ARP** protocol update arp table

Attachments:

```
onlinegod@ubuntu: ~/Desktop
                                                                              Q
onlinegod@ubuntu:~/Desktop$ arp
Address
                                                                      Flags Mask
                                 HWtype
                                          HWaddress
                                                                                                   Iface
 gateway
                                 ether
                                           00:50:56:e6:b2:04
                                                                                                   ens33
onlinegod@ubuntu:~/Desktop$
Администратор: Windows PowerShell
                                                                                           - 🗆 X
PS C:\WINDOWS\system32> ipconfig
Windows IP Configuration
Ethernet adapter Ethernet:
  Connection-specific DNS Suffix .:
Link-local IPv6 Address . . . . : fe80::c106:c32b:fb29:7a5c%14
  IPv4 Address. . . . . . : 192.168.31.23
Subnet Mask . . . . : 255.255.20
  Default Gateway . . . . . . . : 192.168.31.1
Ethernet adapter VMware Network Adapter VMnet1:
  Connection-specific DNS Suffix .:
  Link-local IPv6 Address . . . . . : fe80::90d9:f4d3:c398:8d22%16
  IPv4 Address. . . . . . . . . . : 192.168.32.1
  Default Gateway . . . . . . . . :
Ethernet adapter VMware Network Adapter VMnet8:
  Connection-specific DNS Suffix .:
  Link-local IPv6 Address . . . . : fe80::fc99:c451:90ae:a25b%3
  IPv4 Address. . . . . . . . . . : 192.168.61.1
  Default Gateway . . . . . . . . :
PS C:\WINDOWS\system32>
```



Version: ARP v1

Setup Description:

PC1----ethernet1----PC2

PC1: 192.168.61.128

PC2: 192.168.31.23

Steps (with ER):

1. Check arp table

arp -a <for PC1>

ER: verify that arp table (cache) has no information about PC2

2. Check IP address of PC2

ipconfig <for PC2>

ER: ip of PC2 is shown in PowerShell

- 3. Run Wireshark for ethernet1
- 4. Run ping from PC1 to PC2

ER: ping is running

- 5. Verify that ARP request and ARP reply are present for IP and MAC of PC2 in Wireshark
- 6. Check arp table one more time

$$arp -a < for PC1 >$$

ER: verify that arp table now has information about PC2